No Mirs Prvibling

## LOG OF MEETING

DIRECTORATE FOR ENGINEERING SCIENCES

Excepted by
Comments Processed.

n KMR -5 A 10: 30

CRSC/SEC

SUBJECT: Flammability Tests of Pyrovatex-treated Flame Resistant Fabrics

DATE OF MEETING: January 21, 1998

DATE OF LOG ENTRY: February 11, 1998

SOURCE OF LOG ENTRY: Margaret L. Neily, ESME

LOCATION: CPSC, Room 410 A, East West Towers, Bethesda, MD

CPSC ATTENDEES: Margaret Neily, ESME, and others. See attached list of CPSC attendees.

NON-CPSC ATTENDEES: See attached list of attendees.

SUMMARY OF MEETING: In preparation for updating the laundering/detergent requirements for several Flammable Fabrics Act standards, the CPSC staff tested flame resistant children's sleepwear fabrics after launderings with AATCC 124 (with phosphate and non-phosphate built standard detergents) as well as common household powder and liquid non-phosphate detergents. Fabrics treated with Pyrovatex CP new (Pyrovatex) showed poor flame resistance after laundering with powder non-phosphate detergents.

Ciba Specialty Chemicals representatives reported on their follow-up work to further evaluate the impact of laundering on fabrics treated with Pyrovatex. This study focused on knitwear, although primary uses of Pyrovatex are in workwear and home furnishings. Douglas Parks outlined a number of factors that affect the durability of this flame retardant including product quality, application level, processing steps, other finishing components, fabric weight, fiber content, print coverage, fabric style, fabric/garment care. Chlorine bleach, acid sour rinse, storage at high temperature and humidity can degrade the treatment. Fabric softeners, soap-based detergents, and flammable finishes/prints can render the treatment ineffective.

In order to determine the affect of product care on sleepwear fabrics, Ciba conducted a number of flammability tests. Interlock and 1x1 rib knits and heavier cotton terries were included. Test conditions included unwashed and after 50 launderings with non-phosphate detergents: AATCC 1993, a powder detergent for baby products, a powder concentrate and a liquid concentrate with bleach. The phosphorous levels remained durable to the washing process; however, increases in calcium and magnesium were detected. The interlock knits performed unsatisfactorily with the powder concentrate; rib knits also showed increased char lengths over 3 inches. Cotton terries

maintained very short char lengths under all of these wash conditions. Further tests with the terry fabrics, however, confirmed the adverse affects of laundering with products containing chlorine bleach and of fabric softener added to the rinse cycle.

Ciba Specialty Chemicals has no control over the application process used to apply Pyrovatex (they only sell the chemical) or other care factors that adversely impact the flame resistance of garments in use. With the lighter weight fabrics typically used for sleepwear, there is little room for error. Because of this, the company decided it is prudent to stop marketing Pyrovatex to the sleepwear industry (with one exception, a terry fabric over which they have acceptable control). Ciba plans to publish the results of this study.

## **ATTENDANCE**

## Ciba Specialty Chemicals Tests of Pyrovatex-treated FR Fabrics under the Children's Sleepwear Flammability Standard

January 21, 1998

NAME	COMPANY	PHONE NUMBER
Margaret Neily	CPSC/Engineering	(301) 504-0550, x2354
Marily Borsari	CASC/ Compliance	301 504-0400 X1370
Ljuda Janeter	CPSC/Latisatory Sou	uces 301-413-053
DALE RAY	cps e	311-504-0962
Chuck Smith	CPSC-Economic Analysis	301-504-0962
Donc PARKES	CIBA SPECIALLY	334-801-2484
CARL D'RUIZ	CIBA-SREZIALTY CHOMICALS	336-80-2493
Phil Wakelyn	NCC	202745 7805
BILL REARICK	COTTON INCORIONITED	919-510-6234
Joe Zio IKaus Ki	ATMA	336-884-5000
(Toss Rotson	AFMA	202 466-7360
WREREN Porter	Loc/Lo/asc	301-413-0040
Brus Navam	NAVAMO Leg. LRg. Athr	(202)915-6006
Strippin White	ESMF/CPSC	(301) 5/14-04/08 ext.)
DAVID SCHHELTZER	squire, sandées + Dempsy	202 626-6235
Unistru Cames	PSL	703-524-7634
Pat fanal	CPSC/ Compliance	301-504-0400 X 1369
Fath Polliter	CRSC 06-C	301-1-14-1980 xoles
<del></del>		